




HYPER 212 RGB BLACK EDITION

with RGB Fan

USER MANUAL


01. Package Content

A




x1

B




x1

C




x1

D




x2

E



x2

F



x2

G



x2

H




x4

I



x4

J



x4

K



x4

L



x4

02. Package Content

M  x1	N  x1	O  x1	P  x2	Q  x4
R  x1	S  x1	T  x1	U  x4	V  x4

Intel LGA 1700: C,F,G



Intel LGA 1200/115X/1366: B,D,G,H,J,K

Intel LGA 2066/2011-v3/2011: D,G,L



AM5: E,G,M,V

AM4/AM3+/AM3/AM2+/AM2/FM2+/FM2/FM1: B,E,G,I,J,K



03. Intel & AMD



04. Intel - LGA 1700




05. Intel - LGA 1700




06. Intel - LGA 1200/115X/1366


1




2





3






4






07. Intel - LGA 1200/115X/1366




LGA 1366
LGA 1200/115x





08. Intel - LGA 2066/2011-v3/2011







LGA 2066/2011-v3
/2011




09. Intel - LGA 2066/2011-v3/2011





10. AMD AM5





11. AMD AM5




12. AMD AM4/AM3+/AM3/AM2+/AM2/FM2+/FM2/FM1




13. AMD AM4/AM3+/AM3/AM2+/AM2/FM2+/FM2/FM1




AM3+/AM3/AM2+/
AM2/FM2+/FM2/FM1
AM4




14. AMD AM4/AM3+/AM3/AM2+/AM2/FM2+/FM2/FM1



15. Intel & AMD




16. Intel & AMD




17. The 2nd fan is Optional

- | EN | The 2nd fan is optional
- | CHT | 可選購第二個風扇
- | CHS | 可选购双风扇
- | AR | المروحة الثانية اختيارية
- | BG | Вторият вентилатор е по избор.
- | CS | druhý ventilátor je volitelný
- | DE | Der 2. Lüfter ist optional
- | EL | Ο δεύτερος ανεμιστήρας είναι προαιρετικός
- | ES | El 2o ventilador es opcional
- | FR | Le 2nd ventilateur est optionnel
- | HU | A második ventilátor opcionális
- | ID | Kipas pendingin ke-2 opsional
- | IT | La seconda ventola è optional
- | NL | De tweede fan is optioneel
- | PL | opcjonalnie 2gi wentylator
- | PT | A 2ª ventoinha é opcional
- | RU | Второй вентилятор может быть установлен дополнительно
- | SR | Instalacija dodatnog ventilatora je opcionalna.
- | TR | 2'nci fan opsiyoneldir



18. The 2nd fan is Optional



Please visit our website at www.coolermaster.com

China - Cooler Master China

Room 112, Building 9, No. 327, Songjin Road, Jinshanwei Town, Jinshan Dist.,
Shanghai City, China

Tel: +86-21-51872177

Europe - Cooler Master Europe B.V.

Lodewijkstraat 1b, 5652AC Eindhoven, The Netherlands

Tel: +31- (0)40- 702- 0900

North America – CMI USA, Inc.

1 N Indian Hill Blvd Suite 200, Claremont, CA 91711, USA

Tel: +1-888-624-5099

For the most updated information, please visit our official website: www.coolermaster.com
Cooler Master Support: <https://account.coolermaster.com/>



512004842-GP Ver 2.0 2022/06

©2022 Cooler Master Technology Inc. All Rights Reserved. All trademarks are registered to their respective owners.